

ROSCAS



P – 111 ROSCA
14(1,25)x18(1,5)x16



P – 619 ROSCA
14(1,25)x18(1,5)x21



P – 843 ROSCA
20(1,5)x14(1,25)x16



P – 844 ROSCA
18 (1,5) x 14 (1,25) x 16



P – 845 ROSCA
20(1,5)x14(1,25)x21



P – 861 ROSCA
12 (1,5) x 16 (1,5) x 20



P – 885 ROSCA
10 (1,25) x 14 (1,5) x 16



P – 886 ROSCA
12 (1,25) x 16 (1,5) x 16



P – 887 ROSCA
12 (1,25) x 16 (1,5) x 20



P – 888 ROSCA
12 (1,25) x 16 (1,5) x 30



P – 889 ROSCA
14 (1,25) x 18 (1,5) x 26



P – 890 ROSCA
14 (1,25) x 20 (1,5) x 26



P – 891 ROSCA
14 (1,5) x 18 (1,5) x 26



P – 892 ROSCA
12 (1,5) x 16 (1,5) x 16



P – 897 ROSCA
10 (1,0) x 14 (1,25) x 22
C/ REB. INT.



P – 902 ROSCA
10(1,25)x12(1,25)x21



P – 902A ROSCA
10(1,0)x12(1,25)x 21



P – 903 ROSCA
10(1,0)x12(1,0)x12



Priscar Metalúrgica Ltda.

ROSCAS



P – 904 ROSCA
10(1,0)x12(1,25)x16
ABA 14 -



P – 905 ROSCA
10(1,0)x14(1,5)x16
ABA 18 -



P – 906 ROSCA
10(1,0)x14(1,5)x26
ABA 18 -



P – 907 ROSCA
12(1,5)x14(1,25)x16
ABA 18 -



P – 908 ROSCA
12(1,25) x14(1,25)x21
ABA 18 -



Priscar Metalúrgica Ltda.